

# Geschikte printermodellen

HP AMP  
HP DeskJet 2620 Series  
HP DeskJet 2630 Series  
HP DeskJet 2640 Series  
HP DeskJet 2650 Series  
HP DeskJet 2680 Series  
HP DeskJet 2710 Series  
HP DeskJet 2720 Series  
HP DeskJet 2730 Series  
HP DeskJet 2750 Series  
HP DeskJet 3630 Series  
HP DeskJet 3720 Series  
HP DeskJet 3750 Series  
HP DeskJet 3760 Series  
HP DeskJet 3770 Series  
HP DeskJet Plus 4120 Series  
HP DeskJet Plus 4130 Series  
HP DeskJet Plus 4140 Series  
HP DeskJet Plus 4150 Series  
HP ENVY 4500 Series  
HP ENVY 4510 Series  
HP ENVY 4520 Series  
HP ENVY 5010 Series  
HP ENVY 5020 Series  
HP ENVY 5030 Series  
HP ENVY 5050 Series  
HP ENVY 5070 Series  
HP ENVY 5260 Series  
HP ENVY 5530 Series  
HP ENVY 5540 Series

HP ENVY 5640 Series  
HP ENVY 5660 Series  
HP ENVY 6020 Series  
HP ENVY 6050 Series  
HP ENVY 6070 Series  
HP ENVY 6470 Series  
HP ENVY 7640 Series  
HP ENVY Photo 6220 Series  
HP ENVY Photo 6250 Series  
HP ENVY Photo 7120 Series  
HP ENVY Photo 7150 Series  
HP ENVY Photo 7160 Series  
HP ENVY Photo 7850 Series  
HP ENVY Photo 7860 Series  
HP ENVY Pro 6420 Series  
HP ENVY Pro 6450 Series  
HP ENVY Pro 6470 Series  
HP LaserJet M209dw Printer  
HP LaserJet MFP M234dw Printer  
HP LaserJet MFP M234s Printer  
HP OfficeJet 3830 Series  
HP OfficeJet 4630 Series  
HP OfficeJet 4650 Series  
HP OfficeJet 5210 Series  
HP OfficeJet 5220 Series  
HP OfficeJet 5250 Series  
HP OfficeJet 5260 Series  
HP OfficeJet 5740 Series  
HP OfficeJet 6810 Series

HP OfficeJet 6820 Series  
HP OfficeJet 6950 Series  
HP OfficeJet 6960 Series  
HP OfficeJet 8010 Series  
HP OfficeJet 8020 Series  
HP OfficeJet 8040 Series  
HP OfficeJet 8702 Series  
HP OfficeJet 9010 Series  
HP OfficeJet Pro 6830 Series  
HP OfficeJet Pro 6950 Series  
HP OfficeJet Pro 6960 Series  
HP OfficeJet Pro 6970 Series  
HP OfficeJet Pro 8020 Series  
HP OfficeJet Pro 8030 Series  
HP OfficeJet Pro 8210 Series  
HP OfficeJet Pro 8610 Series  
HP OfficeJet Pro 8620 Series  
HP OfficeJet Pro 8630 Series  
HP OfficeJet Pro 8710 Series  
HP OfficeJet Pro 8720 Series  
HP OfficeJet Pro 8730 Series  
HP OfficeJet Pro 8740 Series  
HP OfficeJet Pro 9010 Series  
HP OfficeJet Pro 9020 Series  
HP OfficeJet Pro Premier  
HP TANGO  
HP TANGO X